

EVERYDAY USE

# AIRBAG SYSTEM Manual

※Read carefully before use.



## USER'S GUIDE

### Instruction for Resin Keyball



#### MUGEN DENKO CO.,LTD.

1-1012 Ikeba Tempaku-ku Nagoya 468-0055 JAPAN  
phone +81-52-807-7750 fax +81-52-807-7901  
E-mail mugen@hit-air.com  
URL www.hit-air.com


www.hit-air.com

### Instruction for Resin Keyball

The resin keyball is used for hit-air vests for lightweight riders.  
Please see this instruction to use the hit-air vest with the resin keyball properly.



The resin keyball is designed to pull out with less tension than usual for lightweight riders.  
Please handle it with care because the resin keyball can be pulled out if the wire loop or connector attached to the keyball is pulled even with light force.




CAUTION ⚠ Do not use the metal keyball on a product that originally has the resin keyball. Also, do not use the resin keyball with a product that originally has the metal keyball. Use of the wrong keyball may cause malfunction or failure, resulting in damage to the product or injury to the user.



When the resin keyball is inserted into the keybox, the red points must be in a horizontal position and hidden.

CAUTION ⚠ Please don't use a resin keyball which is cracked or deformed. If any damage is found, please replace the resin keyball.

### INCORRECT



The red points are visible and not hidden. The resin keyball is not fully inserted.

CAUTION ⚠ Incorrect installation may cause malfunction.